



1. Receptacle outlets needed on walls of every room of a dwelling unit, except bathroom.
2. No point along the floor line of an unbroken wall can be more than 6' from an outlet.
3. An outlet is needed in any wall space of 2' or more.  
(NEC 210-52)